

# Translations:Récupération de batteries/86/en

---

3) Solder the red wire (positive) with the IN+ input of the charge regulator and the black wire (negative) with the IN- input (*image 5*).