

# Translations:Worm Compost Bins/22/en

---

Drill with drill bit to make the hole for the valve tap and fit the stainless ball or butterfly valvetap (1/2" inch or 3/4" inch) with hydraulic fittings.