

Translations:Worm Compost Bins/26/en

Use a large drill bit (hole saw) for making large hole for the ventilation filters. Insert the ventilation filters and fit using silicon.