## Translations: Chauffage solaire version ardoise/83/en

• Place an adhesive joint on the battens of the frame 1mm from the edge, all along the frame. It will serve to welcome the glass.