

Translations:Cuisinière améliorée - Modèle Patsari/46/en

- Use a trowel to dig a passage in the mortar for free access to the smoke venting tunnels and create a circuit between the combustion chamber and the two secondary hotplates.
- Make sure to leave a 2cm tall passage between the hotplate and the dent created in the secondary chambers.
- Dig a passage between the secondary chambers and the base of the chimney flue.