

Translations:Cuisinière améliorée - Modèle Patsari/50/en

- Create a nice, smooth surface by moistening it a little and smoothing with the trowel.
- Carefully remove the formwork around the cooker.
- If necessary, scrape down and smooth the edges of the cooker for a better finish.
- Insert the tubes in the smoke venting ducts to form the chimney flue.
- The stove takes about a week to dry completely.