

Translations:Four solaire (cuisneur type boîte)/33/en

1) Screw the panels C, D and E on the sticks, 3 screws are enough.