

Translations:Phytoépuration eaux usées/177/en

- Install in the manhole a stop-start system (overflow) to keep the basin full of water. The water level needs to come to a few centimeters lower than the gravel. You will need to dig into the gravel to have access to the water.