

Translations:Poelito - Poêle de masse semi-démontable/164/en-gb

- Calculate the volumes needed for casting and increase it by 20 %
- Put the water into the container in which you are going to mix it all up.
- Pour in the cement.
- Mix it up until you have a smooth paste
- Pour all the vermiculite in and mix in until you have an even mixture. The granules should have all turned black and the mix should be sufficiently wet.
- Add more water if necessary.