

# Translations:Poelito - Poêle de masse semi-démontable/186/en-gb

---

- Turn the barrel back over.
- Drill 3 pairs of holes to the diameter of the wire (as per the diagram opposite). It does not have to be exact.
- Loop 1m approx. of wire through. This will help to keep the cardboard moulds in place whilst pouring the concrete.