## Translations:Pompe manuelle (verticale)/23/en-gb

Glue all the parts together and once they have dried, drill a hole in the middle of the 50mm-50mm coupling and insert a screw.