- Position the supporting system on the pillar, at the chosen place.
- Pass the lag screw through the pillar, the mural wedge and the wall which will welcome the toilets.