

Translations:Bélier hydraulique/9/en

To obtain a functional air chamber, you should also empty it from the powder and clean the inside of the extinguisher.