## Translations:Bio Charbon/47/en

3) Position the barrel in the centre of the ring. The air should be able to circulate under the carbonisation machine.