

Translations:Dimensionner une installation photovoltaïque autonome/167/en

-amperage: variable according to the models but generally lower than 10A. See basics recall for addition. You can also make mixed serie/parallele system to adjust