

Translations:Dimensionner une installation photovoltaïque autonome/236/en

1. Enter orientation (south,west,east,nord)

```
aspect_input=input("Enter orientation (south,west,east,nord)") dictaspect={'est':-90,'ouest':90,'nord':180,'sud':0} if aspect_input in dictaspect:
```

```
    aspect=dictaspect[aspect_input]
```

```
else:
```

```
    aspect=0
```