

Translations: Dimensionner une installation photovoltaïque autonome/81/en

NB: the battery capacities are often expressed in Ah. To obtain the Ah from the capacity