

Translations:Eolienne 200W/166/en

Notes: It is **important** that all coils are positioned with **the coils turning in the same direction**, either clockwise or anti-clockwise. If this instruction is not respected, the generator will not function as expected.