

Translations:Eolienne 200W/290/en

- Solder each phase of the output cable to each input terminal of the rectifier.