

# Translations:L'énergie dans l'habitat/59/en

---

The operation of a solar water heater is simple: a heat-carrying fluid passes through insulated tubes that are exposed to the sun. The sun's radiation heats the fluid, and when the temperature of the fluid exceeds that of the hot water tank, a thermostat opens a circulation valve. The fluid then transfers its calories to the water in the tank.