

# Translations:Ordinateur low-tech/26/en

---

In addition, during startup, the red led should stay fixed and the green one should flash for a few seconds before turning off. If this is not the case, and if the Raspberry does not appear to startup on the screen, even after about thirty seconds, **this means that it is unable to startup from the card**. In fact, it is unable to find the code which allows it to 'boot' and install Raspbian.