

Translations:Ordinateur low-tech/29/en

Once the system is started up, it is (probably) going to ask you to identify yourself. **During the first system startup** the default login is 'pi' and the password is 'raspberry'.