

Translations:Powerbank simple/19/en

- Open the computer battery, possibly using the chisel and hammer, while remaining delicate so as not to damage the cells.