

Translations: Remorque génératrice solaire - Système électrique/76/en

- Fuses at the output of each SP string in series (obligatory only if you have more than one SP string/channel, which is not the case on the trailer):
 - $1,5 I_{sc_tot} < I_{fuse} < 2,4 I_{sc_tot}$
 - $1,1 V_{oc_tot} < V_{fuse}$