

# Translations: Remorque génératrice solaire - Système électrique/81/en

---

$I_{op}$  Being the current in operation. It varies if you are in battery charging or discharging mode :