

Translations: Remorque génératrice solaire - Système électrique/87/en

To avoid the losses due to overheating, or even fire risks, it is important to size all the installation cables correctly. That is to say, calculate the minimum section (in mm²) of the cable