Translations: Eolienne 200W/278/en

• Fit the bell hub onto the spindle, carefully repositioning the ball bearings and lock nuts (tighten to the maximum and then loosen a quarter turn). The system must turn freely.