

Translations:Lampe solaire à batteries lithium récupérées/261/en

To measure the capacity of a cell, we have to charge it to the maximum and then discharge it. Those cells are lithium based, and need a specific charge and discharge system, usually the maximal charge is 4,2 V and the minimum is 3V. Going over those limits will damage the cell.