

# Translations:Poelito - Poêle de masse semi-démontable/172/en-gb

---

Unless you have a drum with a detachable lid with strapping, you will need to cut the top off of the drum. The top of the drum is used as the cover for the stove once it has been finished. Avoid damaging it and choose the bottom of the drum (which is a complete unit) in preference to the top (which is where the bungs go). This means turning the drum upside down.