

Translations:Poelito - Poêle de masse semi-démontable/217/en-gb

To adjust the secondary air flow, all you need is to put the lid half-on. The lid will never be totally closed down during use. At the end of use, the lid is to be closed. This stops the hot stove from sucking in air into the unit, warming it up and escaping out.